

Appendix

A: Extra header examples

The example extra header structures below include additional white space and formatting for readability, which should not be used in an actual record.

FDSN reserved extra headers

A relatively simple example of reserved FDSN extra headers that contains a timing quality value and an event detection is:

```

{
  "FDSN": {
    "Time": {
      "Quality": 100,
      "Correction": 1.234
    },
    "Event": {
      "Begin": true,
      "End": true,
      "InProgress": true,
      "Detection": [
        {
          "Type": "MURDOCK",
          "SignalAmplitude": 80,
          "SignalPeriod": 0.4,
          "BackgroundEstimate": 18,
          "Wave": "DILATATION",
          "Units": "COUNTS",
          "OnsetTime": "2022-06-05T20:32:39.120000Z",
          "MEDSNR": [ 1, 3, 2, 1, 4, 0 ],
          "MEDLookback": 2,
          "MEDPickAlgorithm": 0,
          "Detector": "Z_SPWSS"
        }
      ]
    }
  }
}

```

An example of the reserved FDSN headers defined by the FDSN is provided below. In this (pathological) illustration, all reserved fields are represented.

```

{
  "FDSN": {
    "Time": {
      "Quality": 100,
      "Correction": 1.234,
      "MaxEstimatedError": 1e-06,
      "LeapSecond": 1,
      "Exception": [
        {
          "Time": "2022-05-06T20:32:41.12Z",
          "VCOCorrection": 50.7812,
          "ReceptionQuality": 80,
          "Count": 23,
          "Type": "Valid Timemark",
          "ClockStatus": "SNR=48,51,51,50,50,48,46,48,45,45"
        },
        {
          "Time": "2022-05-06T20:32:42.185Z",
          "VCOCorrection": 44.1313,
          "ReceptionQuality": 55,
          "Count": 19690,
          "Type": "Missing timemarks",
          "ClockStatus": "SNR=50,48,46,48,48,45,45"
        }
      ]
    },
    "Event": {
      "Begin": true,
      "End": true,
      "InProgress": true,
      "Detection": [
        {
          "Type": "GENERIC",
          "SignalAmplitude": 80,
          "SignalPeriod": 0.4,
          "BackgroundEstimate": 18,
          "OnsetTime": "2022-05-06T20:32:39.120000Z",
          "Detector": "Dalek STA/LTA"
        },
        {
          "Type": "MURDOCK",
          "SignalAmplitude": 80,
          "SignalPeriod": 0.4,
          "BackgroundEstimate": 18,
          "Wave": "DILATATION",
          "Units": "COUNTS",
          "OnsetTime": "2022-05-06T20:32:39.185000Z",
          "MEDSNR": [ 1, 3, 2, 1, 4, 0 ],
          "MEDLookback": 2,
          "MEDPickAlgorithm": 0,
          "Detector": "Z_SPWSS"
        }
      ]
    },
    "Calibration": {
      "Sequence": [
        {
          "Type": "Step",
          "BeginTime": "2022-05-06T20:32:39.120000Z",
          "Steps": 12,
          "StepFirstPulsePositive": true,
          "StepAlternateSign": true,
          "Trigger": "AUTOMATIC",

```

```
"Continued": false,
"Amplitude": 1345,
"InputUnits": "COUNTS",
"Duration": 603.456,
"SinePeriod": 5.0,
"StepBetween": 500.0,
"InputChannel": "CAL",
"ReferenceAmplitude": 45.8,
"Coupling": "RESISTIVE",
"Rolloff": "Description of rolloff"
},
{
  "Type": "Step",
  "EndTime": "2022-05-06T20:32:39.120000Z"
},
{
  "Type": "Sine",
  "BeginTime": "2022-05-06T20:32:39.120000Z",
  "EndTime": "2022-05-06T20:32:39.120000Z",
  "Trigger": "MANUAL",
  "Continued": true,
  "Amplitude": 1345,
  "InputUnits": "COUNTS",
  "AmplitudeRange": "PEAKTOPEAK",
  "SinePeriod": 5.0,
  "InputChannel": "CAL",
  "ReferenceAmplitude": 45.8,
  "Coupling": "RESISTIVE",
  "Rolloff": "Description of rolloff"
},
{
  "Type": "PseudoRandom",
  "BeginTime": "2022-05-06T20:32:39.120000Z",
  "EndTime": "2022-05-06T20:32:39.120000Z",
  "Trigger": "MANUAL",
  "Amplitude": 0.0001,
  "InputUnits": "M/S",
  "Duration": 300,
  "InputChannel": "CAL",
  "ReferenceAmplitude": 45.8,
  "Coupling": "CAPACITIVE",
  "Rolloff": "Very randomly",
  "Noise": "White"
},
{
  "Type": "Generic",
  "BeginTime": "2022-05-06T20:32:39.120000Z",
  "EndTime": "2022-05-06T20:32:39.120000Z",
  "Trigger": "MANUAL",
  "Amplitude": 1345,
  "Duration": 100
}
]
},
"Recenter": {
  "Sequence": [
    {
      "Type": "Gimbal",
      "BeginTime": "2022-05-06T20:32:39.120000Z",
      "EndTime": "2022-05-06T20:32:39.120000Z",
      "Trigger": "AUTOMATIC"
    },
    {
      "BeginTime": "2022-05-06T20:32:40.120000Z"
```

```
    }
  ]
},
"Flags": {
  "MassPositionOffscale": true,
  "AmplifierSaturation": true,
  "DigitizerClipping": true,
  "Spikes": true,
  "Glitches": true,
  "FilterCharging": true,
  "StationVolumeParityError": true,
  "LongRecordRead": true,
  "ShortRecordRead": true,
  "StartOfTimeSeries": true,
  "EndOfTimeSeries": true,
  "MissingData": true,
  "TelemetrySyncError": true
},
"Logger": {
  "Model": "DM24",
  "Serial": "A4567"
},
"Sensor": {
  "Model": "T240",
  "Serial": "123123"
},
"Clock": {
  "Model": "P273T11N16",
  "Serial": "24A00000"
},
"ProvenanceURI": "prov:sp001_wf_f84fb9a",
"DataQuality": "D",
"Sequence": 123456
}
```

Non-FDSN extra headers

An example of reserved FDSN headers combined with other top-level headers, illustrating how custom headers may be added.

```
{
  "FDSN": {
    "Time": {
      "Quality": 90
    }
  },
  "Manufacturer123": {
    "Metadata": {
      "FilamentCurrent": 16.4,
      "HyperCoordinates": "1.1789:965402:73324@3.14159"
    }
  },
  "OperatorXYZ": {
    "DSP": {
      "PeakRMS": 2067,
      "RMSWindow": 10.5
    }
  }
}
```

B: Reference data

The reference data set is intended as an illustration of properly constructed miniSEED 3 and to be used by software implementors during development and testing.

The set contains multiple examples of data records illustrating different characteristics and data encodings of the from. Each example is available in miniSEED 3, JSON, and human-readable text representations.

The whole data set may be downloaded from documentation repository.

All time series in the reference set that contain series are the same expanding sinusoid signal.

#	Description	Download
1	Text payload	↓ mseed3 ↓ JSON ↓ Te:
2	Event detection headers only, no data payload	↓ mseed3 ↓ JSON ↓ Te:
3	Sinusoid series encoded as 16-bit integers	↓ mseed3 ↓ JSON ↓ Te:
4	Sinusoid series encoded as 32-bit integers	↓ mseed3 ↓ JSON ↓ Te:
5	Sinusoid series encoded as 32-bit IEEE float	↓ mseed3 ↓ JSON ↓ Te:
6	Sinusoid series encoded as 64-bit IEEE float	↓ mseed3 ↓ JSON ↓ Te:
7	Sinusoid series encoded as Steim-1 compressed integers	↓ mseed3 ↓ JSON ↓ Te:
8	Sinusoid series encoded as Steim-2 compressed integers	↓ mseed3 ↓ JSON ↓ Te: latest ▼
9	Series with time quality, correction, event detections headers	↓ mseed3 ↓ JSON ↓ Te:

#	Description	Download
10	Series with some FDSN and non-FDSN extra headers	↓ mseed3 ↓ JSON ↓ Te:
11	Series with all FDSN extra headers (unrealistic)	↓ mseed3 ↓ JSON ↓ Te:

C: Mapping from miniSEED 2.4

The following list of miniSEED 2.4 format structures specifies the mapping of all fields to this specification. In this listing the following abbreviations are used:

- EH:** Extra Header (of this specification), with path
- SID:** Source Identifier (of this specification)
- FSDH:** Fixed Section Data Header (in either specification)

miniSEED 2.4 Fixed Section Data Header (FSDH)

Field	Description	This specification										
1	Sequence number	EH: <i>FDSN.Sequence</i>										
2	Data header/quality indicator	EH: <i>FDSN.DataQuality</i> A data center may choose to translate miniSEED 2.4 quality values to publication versions with the following mapping: <table><tr><th>2.4 quality</th><th>Pub. version</th></tr><tr><td>R</td><td>1</td></tr><tr><td>D</td><td>2</td></tr><tr><td>Q</td><td>3</td></tr><tr><td>M</td><td>4</td></tr></table>	2.4 quality	Pub. version	R	1	D	2	Q	3	M	4
2.4 quality	Pub. version											
R	1											
D	2											
Q	3											
M	4											
3	Reserved byte	[no mapping]										
4	Station identifier code	Incorporated into SID, FSDH field 13										
5	Location identifier	Incorporated into SID, FSDH field 13										
6	Channel identifier	Incorporated into SID, FSDH field 13										
7	Network code	Incorporated into SID, FSDH field 13										
8	Record start time	FSDH field 4										
9	Number of samples	FSDH field 7										
10	Sample rate factor	Incorporated into FSDH field 6										

Field	Description	This specification
11	Sample rate multiplier	Incorporated into FSDH field 6
12	Activity flags: 0 = calibration signals 1 = time correction applied 2 = begining of event 3 = end of event 4 = + leap second included 5 = - leap second included 6 = event in progress	FSDH and Extra headers: - FSDH field 3, bit 0 [no mapping] <i>FDSN.Event.Begin</i> <i>FDSN.Event.End</i> <i>FDSN.Time.LeapSecond</i> <i>FDSN.Time.LeapSecond</i> <i>FDSN.Event.InProgress</i>
13	I/O flags, bits: 0 = Sta. volume parity error 1 = Long record read 2 = Short record read 3 = Start of time series 4 = End of time series 5 = Clock locked	FSDH and Extra headers: <i>FDSN.Flags.StationVolumeParityError</i> <i>FDSN.Flags.LongRecordRead</i> <i>FDSN.Flags.ShortRecordRead</i> <i>FDSN.Flags.StartOfTimeSeries</i> <i>FDSN.Flags.EndOfTimeSeries</i> - FSDH field 3, bit 2
14	Data quality flags, bits: 0 = Amp. saturation detected 1 = Dig. clipping detected 2 = Spikes detected 3 = Glitches detected 4 = Missing/padded data 5 = Telemetry synch. error 6 = Digital filter charging 7 = Time tag questionable	FSDH and Extra headers: <i>FDSN.Flags.AmplifierSaturation</i> <i>FDSN.Flags.DigitizerClipping</i> <i>FDSN.Flags.Spikes</i> <i>FDSN.Flags.Glitches</i> <i>FDSN.Flags.MissingData</i> <i>FDSN.Flags.TelemetrySyncError</i> <i>FDSN.Flags.FilterCharging</i> - FSDH field 3, bit 1
15	Number of blockettes that follow	[no mapping]
16	Time correction	EH: <i>FDSN.Time.Correction</i>
17	Beginning of data	[no mapping]
18	First blockette	[no mapping]

Blockette 100 (Sample Rate)

Field	Description	This specification
3	Actual sample rate	FSDH field 6

Field	Description	This specification
4	Flags (undefined)	[no mapping]
4	Reserved byte	[no mapping]

Blockette 200 (Generic Event Detection)

Field	Description	This specification
3	Signal amplitude	EH: <i>FDSN.Event.Detection.SignalAmplitude</i>
4	Signal period	EH: <i>FDSN.Event.Detection.SignalPeriod</i>
5	Background estimate	EH: <i>FDSN.Event.Detection.BackgroundEstimate</i>
6	Event detection flag bits: 0 = dil./comp. wave 1 = units	Extra headers: <i>FDSN.Event.Detection.Wave</i> <i>FDSN.Event.Detection.Units</i>
7	Reserved byte	[no mapping]
8	Signal onset time	EH: <i>FDSN.Event.Detection.OnsetTime</i>
9	Detector name	EH: <i>FDSN.Event.Detection.Detector</i>

Blockette 201 (Murdock Event Detection)

Field	Description	This specification
3	Signal amplitude	EH: <i>FDSN.Event.Detection.SignalAmplitude</i>
4	Signal period	EH: <i>FDSN.Event.Detection.SignalPeriod</i>
5	Background estimate	EH: <i>FDSN.Event.Detection.BackgroundEstimate</i>
6	Event detection flag bits: 0 = dil./comp. wave	Extra headers: <i>FDSN.Event.Detection.Wave</i>
7	Reserved byte	[no mapping]
8	Signal onset time	EH: <i>FDSN.Event.Detection.OnsetTime</i>
9	Signal-to-noise values	EH: <i>FDSN.Event.Detection.MEDSNR</i> (array)
10	Lookback value	EH: <i>FDSN.Event.Detection.MEDLookback</i>
11	Pick algorithm	EH: <i>FDSN.Event.Detection.MEDPickAlgorithm</i>
12	Detector name	EH: <i>FDSN.Event.Detection.Detector</i>

Blockette 300 (Step Calibration)

Field	Description	This specification
3	Start calib	EH: <i>FDSN.Calibration.Sequence.Begintime</i>
4	Num of calibs	EH: <i>FDSN.Calibration.Sequence.Steps</i>
5	Calibration flags: 0 = first pulse 1 = cal alt sign 2 = cal auto 3 = cal cont	Extra headers: <i>FDSN.Calibration.Sequence.StepFirstPulsePositive</i> <i>FDSN.Calibration.Sequence.StepAlternateSign</i> <i>FDSN.Calibration.Sequence.Trigger</i> <i>FDSN.Calibration.Sequence.Continued</i>
6	Duration of step	EH: <i>FDSN.Calibration.Sequence.Duration</i>
7	Time between steps	EH: <i>FDSN.Calibration.Sequence.StepBetween</i>
8	Amp. of cal. signal	EH: <i>FDSN.Calibration.Sequence.Amplitude</i>
9	Channel cal. signal	EH: <i>FDSN.Calibration.Sequence.InputChannel</i>
10	Reserved byte	[no mapping]
11	Reference amplitude	EH: <i>FDSN.Calibration.Sequence.ReferenceAmplitude</i>
12	Coupling of signal	EH: <i>FDSN.Calibration.Sequence.Coupling</i>
13	Rolloff of filters	EH: <i>FDSN.Calibration.Sequence.Rolloff</i>

Blockette 310 (Sine Calibration)

Field	Description	This specification
3	Start calib	EH: <i>FDSN.Calibration.Sequence.Begintime</i>
4	Reserved byte	[no mapping]
5	Calibration flags: 2 = cal auto 3 = cal cont 4 = PtoP amp 5 = ZtoP amp 6 = RMS amp	Extra headers: <i>FDSN.Calibration.Sequence.Trigger</i> <i>FDSN.Calibration.Sequence.Continued</i> <i>FDSN.Calibration.Sequence.AmplitudeRange</i> <i>FDSN.Calibration.Sequence.AmplitudeRange</i> <i>FDSN.Calibration.Sequence.AmplitudeRange</i>
6	Duration of cal	EH: <i>FDSN.Calibration.Sequence.Duration</i>
7	Period of signal	EH: <i>FDSN.Calibration.Sequence.Period</i>
8	Amp. of cal. signal	EH: <i>FDSN.Calibration.Sequence.Amplitude</i>
9	Channel cal. signal	EH: <i>FDSN.Calibration.Sequence.InputChanr</i>
10	Reserved byte	[no mapping]

Field	Description	This specification
11	Reference amplitude	EH: <i>FDSN.Calibration.Sequence.ReferenceAmplitude</i>
12	Coupling of signal	EH: <i>FDSN.Calibration.Sequence.Coupling</i>
13	Rolloff of filters	EH: <i>FDSN.Calibration.Sequence.Rolloff</i>

Blockette 320 (Pseudo-random Calibration)

Field	Description	This specification
3	Start calib	EH: <i>FDSN.Calibration.Sequence.Begintime</i>
10	Reserved byte	[no mapping]
5	Calibration flags: 2 = cal auto 3 = cal cont 4 = Random amps	Extra headers: <i>FDSN.Calibration.Sequence.Trigger</i> <i>FDSN.Calibration.Sequence.Continued</i> <i>FDSN.Calibration.Sequence.AmplitudeRange</i>
6	Duration of cal	EH: <i>FDSN.Calibration.Sequence.Duration</i>
7	PtoP amp. of steps	EH: <i>FDSN.Calibration.Sequence.Amplitude</i>
8	Channel cal. signal	EH: <i>FDSN.Calibration.Sequence.InputChannel</i>
9	Reserved byte	[no mapping]
10	Reference amplitude	EH: <i>FDSN.Calibration.Sequence.ReferenceAmplitude</i>
11	Coupling of signal	EH: <i>FDSN.Calibration.Sequence.Coupling</i>
12	Rolloff of filters	EH: <i>FDSN.Calibration.Sequence.Rolloff</i>
13	Noise type	EH: <i>FDSN.Calibration.Sequence.Noise</i>

Blockette 390 (Generic Calibration)

Field	Description	This specification
3	Start calib	EH: <i>FDSN.Calibration.Sequence.Begintime</i>
10	Reserved byte	[no mapping]
5	Calibration flags: 2 = cal auto 3 = cal cont	Extra headers: <i>FDSN.Calibration.Sequence.Trigger</i> <i>FDSN.Calibration.Sequence.Continued</i>
6	Duration of cal	EH: <i>FDSN.Calibration.Sequence.Duration</i>
7	Amplitude of signal	EH: <i>FDSN.Calibration.Sequence.Amplitude</i>

Field	Description	This specification
8	Channel cal. signal	EH: <i>FDSN.Calibration.Sequence.InputChannel</i>
9	Reserved byte	[no mapping]

Blockette 395 (Calibration Abort)

Field	Description	This specification
3	End calib	EH: <i>FDSN.Calibration.Sequence.Endtime</i>
10	Reserved byte	[no mapping]

Blockette 400 (Beam), Blockette 405 (Beam Delay)

No mapping for these blockettes

Blockette 500 (Timing)

Field	Description	This specification
3	VCO correction	EH: <i>FDSN.Time.Exception.VCOCorrection</i>
4	Time of exception	EH: <i>FDSN.Time.Exception.Time</i>
5	Microsecond offset	[included in record start time]
6	Reception quality	EH: <i>FDSN.Time.Exception.ReceptionQuality</i>
7	Exception count	EH: <i>FDSN.Time.Exception.Count</i>
8	Exception type	EH: <i>FDSN.Time.Exception.Type</i>
9	Clock model	EH: <i>FDSN.Clock.Model</i>
10	Clock status	EH: <i>FDSN.Time.Exception.ClockStatus</i>

Blockette 1000 (Data Only SEED)

Field	Description	This specification
3	Encoding format	FSDH field 5
4	Word order	[no mapping, no longer needed]
5	Data record length	[no mapping, no longer needed]
6	Reserved byte	[no mapping]

Blockette 1001 (Data Extension)

 [latest](#) ▼

Field	Description	This specification
3	Timing quality	EH: <i>FDSN.Time.Quality</i>
4	Microsecond offset	Incorporated into FSDH field 4
5	Reserved byte	[no mapping]
6	Frame count	[no mapping]

Blockette 2000 (Variable Length Opaque)

No mapping for this blockette. The opaque data encoding may be used to specify an opaque payload for nearly equivalent functionality.

Unsupported miniSEED 2.4 content

The following defined information in miniSEED 2.4 cannot be represented in this specification:

- Clock model specification per timing exception. Current specification only allows a single clock model specification per record.
- Blockettes 400 (Beam) & 405 (Beam Delay)
- Blockette 2000 (Opaque Data)